






Base Installation Quick Guide

en zh


Version: 01
Part Number: 3101002004



4




5




6


en Connection between Base SUB and Base SUB zh Base SUB与Base SUB间对接关系		en Connection between Base SUB and Base MAIN zh Base SUB与Base MAIN间对接关系		en Wiring diagram zh 接线图示	
Base SUB	Base SUB	Base MAIN			
B+	B-	B+	B-	Base MAIN-0.5C/Base SUB-0.5C	Base MAIN-1C/Base SUB-1C
B+_R	B+_L	B+_R	B+_L		
BAL_R	BAL_L	BAL_R	BAL_L		
COM_R	COM_L	COM_R	COM_L		




7




8




9



10



11



en Due to product upgrades or other reasons, this document will be updated irregularly. The printed materials inside the box will not be collected and reprinted. Unless specially agreed upon, this document serves as a user guide only, and its contents cannot replace product labels or manuals. The device warranty does not cover damage caused by not following the instructions in this document and manual.

zh 由于产品升级或其他原因, 本文档将不定期更新, 随箱文件不回收重新印制。除非特殊约定, 本文档仅作为使用指导, 内容不可取代产品标签或手册。未按照本文档与手册的内容操作、使用设备而导致损坏, 不在设备质保范围内。